



**1885606**


**Sullivan Quilt Rack**

**Parts and Hardware List**


A.	Side Frames	2 pcs
B.	Upper & Lower Stretchers	3 pcs
C.	Central Stretchers	4 pcs
D.	Allen Head Bolts	6 pcs
E.	Lock Washers	6 pcs
F.	Flat Washers	6 pcs
G.	Allen Head Wrench	1 pc
H.	Covers	6 pcs
I.	Optional Allen Head Screwdriver Bit	1 pc

- \* Please make sure that you have all the parts and hardware indicated above before you begin assembly of this item.
- \* Use the hardware illustrations to determine correct piece and size.
- \* This item should be assembled on a soft surface to prevent scratching the finish during assembly.
- \* This item may require periodic tightening.
- \* Take care not to overtighten bolts if using supplied Allen Head Screwdriver Bit.


**Hardware Illustrations**




D. Allen Head Bolt



E. Lock Washer



F. Flat Lock Washer




H. Cover

**1885606**  
**Sullivan Quilt Rack**

**Assembly Instructions**

1. **Attach the Stretchers (B & C)** Insert the exposed dowels of Central Stretchers (C) into the pre-drilled holes in Side Panels (A). Align the pre-drilled holes in Side Panels (A) with the pre-threaded holes in Upper & Lower Stretchers (B). Secure the Side Panels (A) to Upper & Lower Stretchers (B) with Allen Head Bolts (D), Lock Washers (E), Flat Washers (F) and Allen Head Tool (G or I). See illustration.
2. **Attach Covers (H)** Insert the Covers (H) into the pre-drilled holes in Side Panels (A). See illustration.



**Illustration**